

Open Sight Regulation



- 1 Turn the screw as indicated in the photo to turn the sight up or down.



- 2 Turn the screw as indicated in the photo to the correct windage.

Laser Sight On/Off switch



- ▶ Press the button indicated by the arrow for one second to turn the laser device ON or OFF.

Laser Sight Regulation




- 1 Turn the screw as indicated in the photo to raise or lower the laser dot.



- 2 Turn the screw as indicated in the photo to the correct in windage.

Battery replacement



- ▶ Unlock with the finger and pull the battery tray.